

### CNP CDLF8 SPARE PARTS

KEY	DESCRIPTION	PART #
1	Coupling guard	
1a	Coupling guard (No cutout)	
2	Screw M4 x 8mm	
3	Pump head	
4	Diffuser	711788
4a	Support diffuser	711792
4b	Neck ring cover	
4c	Neck ring	
5	Coupling	
5a	Inducer	
7	Shaft pin	
8	Nut M16, Washer $\Phi$ 16	
9	Hexagon socket head screw	
10	Circlip cover	
14	Strap	
17	Impeller sleeve	
20	Flange	711794
21	Circlip	
22	First impeller cover	711781
23	Nut M12, Washer $\Phi$ 12	
25	Stay bolt	
26b	Flange type inlet & outlet chamber	711782
28	Drainage screw M10	
29	Drainage nut	711783
30	O ring 169.3 x $\Phi$ 3.3mm	
31	O ring 8 x $\Phi$ 2.65mm	711784
33	Impeller sleeve(S)	
33a	Impeller sleeve(L)	
34	Mechanical seal - Type 2 Hexagonal Cartridge	800240
34	Mechanical seal - Type 3 Triangular Cartridge	800241
36	Air vent nut	
37	O ring 16 x V2.65mm	711787
38	Air vent screw	
39	Bolt, washer to suit motor	
40	Motor	
46	Adjusting rubber	
47a	Bearing	711789
49	Impeller	711790
50a	Top diffuser	711793
51	Shaft	
55	Cylinder	
63	O ring retainer	711795
65	Screw M8 x $\Phi$ 20mm	
68	Screw M12 x $\Phi$ 40mm	

